
# NET 363 Introduction to LANs

# Data Packets: Protocols and Addresses

Greg Brewster
DePaul University

### Packets?

- All network communications is done using data packets. A packet is a sequence of bits sent over a link containing:
  - An initial set of bytes called the packet headers, which contain control information about how and where to transmit the packet across the network
  - The application data (either Request or Response)
  - Possibly, packet trailer bytes at the end.




### Maximum Packet Size

- Packets can't be too large. There is a maximum packet size (or <u>maximum transmission unit – MTU</u>).
- For example: maximum Ethernet packet size is 1500 bytes of user data (more or less). We will assume MTU = 1500 bytes unless otherwise stated.
- Clients typically send single-packet Requests. Servers typically send multi-packet Responses.
  - Because Requests are small enough to fit in 1 packet, but Responses are often too large to fit in 1 packet.

## Multi-packet Response

For example, a server Response for downloading a 1.5
 Mbyte web page requires over 1000 packets to send.



### **Protocols**

- Clients and servers must follow a set of rules called a protocol which determines
  - Packet format
    - Permissible requests and responses
    - Format of header information and data
  - Packet ordering and timing
- Protocol standards are documents that define protocols.
  - For Internet applications, protocol standards are called <u>Request</u> for Comments (RFCs).
    - http://www.rfc-editor.org/rfcsearch.html

## TCP/IP Model Layers

#### Application Protocol

- Controls the exchange of Requests and Responses between the client process and the server process.
- Examples: Hypertext Transfer Protocol (HTTP), Simple Mail Transport Protocol (SMTP), etc.

#### Transport Protocol

- Implements Flow Control and Error Control, if needed. Includes Port Numbers identifying the application process.
- Examples: Transmission Control Protocol (TCP), User Datagram Protocol (UDP)


#### Internet Protocol

- Controls the routing of the packet across the Internet.
- Examples: IPv4, IPv6, IPSec (secure IP)


#### Data Link Protocol

- Controls the sending of a packet across a single subnet.
- Examples: Ethernet, Point to Point Protocol (PPP), etc.

# Example: Web (HTTP)



## Each Layer Adds a Header




Greg Brewster, DePaul University

**HTTP** Request


# Why All The Layers?

- Why do we need multiple layers?
- Each header is only viewed and used by certain devices.
  - The <u>Ethernet header</u> is used by Ethernet hubs and switches.
  - The <u>IP header</u> is used by IP routers
  - The <u>TCP header</u> is used by PCs and servers for error detection/correction.
  - The <u>application header</u> (i.e. HTTP) is used by the application (i.e. browser)

#### **Network Topology**



#### **Data Flow**



Source: Wikipedia

## Addresses


- Addresses identify systems at each layer
- Data Link level address
  - Local physical address (like serial number)
  - Example: Ethernet 6-byte MAC: 00:1a:23:43:22:0d
- Network level address
  - Global logical address (assigned by net admin)
  - Example: <u>IPv4 address</u> (140.192.33.2)
- Transport level address
  - Identifies software process on a machine
  - Example: <u>TCP/UDP Port number</u> (port 80 for web server)

### Ethernet MAC addresses


- Every Ethernet interface has a 6-byte physical address or MAC (medium access control) address assigned and burned into the interface hardware when it is manufactured.
- MAC address is like a serial number.
- MAC address of every Ethernet device is guaranteed to be globally unique.

## Device addresses

Address information (both MAC and IP) for a network connection can be found in Connection Details or by running "ipconfig /all" on Windows. (For Mac: "ifconfig" in Terminal or "About this Mac").




# Ethernet MAC Address format (length = 6 bytes = 48 bits)



- Manufacturer IDs are uniquely assigned to Ethernet equipment manufacturers by IEEE (Institute for Electrical and Electronics Engineers).
- Each manufacturer ensures that each Ethernet interface on every device they make has a unique Serial Number.
- Result: every Ethernet interface has unique address.

# Ethernet MAC Address format (length = 6 bytes = 48 bits)



#### Special address bits:

- Globally/Locally Administered bit determines if this address was allocated by IEEE (0) or locally generated (1).
- Unicast/Multicast bit determines if this address corresponds to a single device (0) or a group of devices (1).
- If all 48 bits are set to 1 (FF:FF:FF:FF:FF:FF) this is the <u>broadcast</u> <u>address</u> which causes data packet to be copied to every device on the LAN.

### **IPv4 Addresses**

- Each IP address is 4 bytes long
- Dotted decimal notation
  - Each byte (8 bits) is written in decimal separated by dots, like
  - Each of the 4 values is in range 0 -255.
  - Example: 150.21.39.52

## **IP Addresses**

- IP addressing is <u>hierarchical.</u>
- In "Classful Addressing" an IP address contains 3 parts:
  - An <u>IP Network</u> part that is used by Internet backbone routers to deliver packets to a particular IP Network. IP Network values are assigned by Internet Assigned Numbers Authority (<u>www.iana.org</u>) to guarantee global uniqueness.
  - An IP Subnet part that is used by internal routers within an IP Network to deliver packets to a particular Subnet. Subnet address values are assigned by local network administration.
  - An IP Host part that identifies a particular individual device on the subnet. Chosen by network admin or randomly assigned from subnet address pool by DHCP server.

## Address Example

Network		Subnet	Host
130	88	55	12

Network = 130.88.0.0/16Subnet Mask = 255.255.255.0Subnet = 130.88.55.0/24Host = 12

# DePaul IP Addressing (140.192.0.0/16 block)

- DePaul University was assigned IP Network prefix
  140.192.0.0/16 by the IANA back in the 1980s. This is a
  Class B address. So, DePaul controls all IP addresses that start with 140.192 in 1<sup>st</sup> 2 bytes (140.192.0.0 140.192.255.255).
- DePaul Information Services (IS) assigns <u>Subnet IDs</u> to various departments and groups at the university. For example:
  - IP subnet 140.192.32.0/24 CTI servers
  - IP subnet 140.192.34.0/24 6<sup>th</sup> and 7<sup>th</sup> floor CTI office PCs
  - IP subnet 140.192.35.0/24 8<sup>th</sup> and 9<sup>th</sup> floor CTI office PCs
- Individual devices in each subnet are then each assigned a unique <u>Host ID</u>, either manually or automatically (using Dynamic Host Configuration Protocol (DHCP)).

### **DHCP**

- How does a device get assigned an IP address?
  - Network admin could do static configuration.
  - OR device can broadcast to DHCP server (Dynamic Host Configuration Protocol) to obtain the <u>4 IP Host</u>
     <u>Configuration Values</u> required to send IP data:
    - IP Address
    - Subnet Mask
    - Default Gateway IP (router interface on subnet)
    - DNS Server IP address
- DHCP server maintains pool of free IP addresses for each subnet and allocates with a *lease time*.

#### **TCP/UDP Ports**

- TCP and UDP headers contain two 2-byte Port Numbers:
  - Source Port
  - Destination Port
- A Port Number identifies a particular <u>software process</u> running on a computer
  - When a client process (such as a browser window) starts up, the operating system assigns it an unused <u>Private Port Number</u>.
  - When a server process (such as a Web server)
     executes, the operating system binds it to a <u>Well-Known</u> or <u>Registered Port number</u> based on its
    function.

## Port Number Ranges


- 3 defined ranges of port numbers:
  - Well Known Ports (0-1023)
    - These port numbers are specified by IANA to identify globally recognized server applications. They never change.
  - Registered Ports (1024-49151)
    - These port numbers are assigned by software vendors for new server processes. IANA may register these port numbers, but global use of registered numbers is not required.
  - Dynamic/Private Ports (49151-65535)
    - These port numbers are locally assigned to client processes.
- See <a href="http://www.iana.org/assignments/port-numbers">http://www.iana.org/assignments/port-numbers</a>

#### **Some Well-Known Port Numbers**

(memorize for CCNA)


- Echo (ping) = UDP port 7
- File Transfer (FTP) = TCP port 21
- Secure Shell (SSH) = TCP port 22
- Remote login (Telnet) = TCP port 23
- E-mail (SMTP) = TCP port 25
- DNS = UDP port 53
- HTTP (Web) = TCP port 80
- Post Office Protocol (POP3) = TCP port 110
- ... and many, many more!!

# Addressing Example: Web Request (assuming src/dest on same subnet)




# (Wired) Ethernet Frame Header

- Ethernet frame header:
  - <u>Preamble</u> field contains fixed bit values for synchronizing sender and receiver clocks.
  - <u>Destination</u> and <u>Source</u> MAC addresses (6 bytes each).
  - <u>Ethernet Type</u> field used to identify the protocol carried in the next header (IP, ARP, AppleTalk, etc.)
- Ethernet frame trailer
  - FCS used for error checking.




### IPv4 Header




#### **DNS Names**

- There are **Domain Name System (DNS)** servers on the Internet that translate from a DNS Name to an IP address.
- Client sends DNS Request with DNS name to DNS Server
- DNS Server sends DNS Response with corresponding IP Address.




## Domain Name System

A system of Domain Name System (DNS) servers allows users to refer to any device by DNS Name (i.e. brewster.cs.depaul.edu) rather than by IP address (i.e. 140.192.32.9)



# DNS Lookup to get to Gmail



IP address of local DNS Server (208.72.26.33 in this example) must be configured into device.


# How does a PC find IP/MAC address of DNS name?

- User types a DNS name: i.e. "www.depaul.edu"
- PC sends <u>DNS Request</u> packet to DNS server and gets back the IP address of destination.
- Then PC can use <u>ARP</u> to find the Physical / MAC / Ethernet Address associated with the IP address:
  - PC checks in local ARP Cache might already be there.
  - If not and if destination is on local subnet, PC broadcasts an <u>ARP Request</u> packet and gets back the Physical address of destination, and sends packet directly to destination.
  - If destination is on a remote subnet, then PC forwards the packet to the local router (called the default gateway).

# Address Resolution Protocol (ARP)

- ARP is a broadcast protocol used to determine the MAC address corresponding to a known IP address
  - ARP Request packet containing an IP address is broadcast on a subnet.
  - ARP Reply is sent by device that recognizes its IP address in the ARP Request.
  - IP Address/MAC Address pairs are stored in ARP Table (also called ARP cache) by the sender so ARP Request does not need to be re-sent for the same destination.

## **ARP Process**




## Viewing your ARP Cache

 You can view the contents of your computer's ARP Cache using the 'arp –a' command (PC or Mac)

```
C:\WINDOWS\system32\cmd.exe
C:\Documents and Settings\gbrewster>arp -a
Interface: 140.192.35.133 --- 0x2
  Internet Address
                        Physical Address
                                              Type
 140.192.35.199
                       00-0d-56-a1-6a-cb
                                              dynamic
                       00-14-f1-ab-60-00
  140.192.35.248
                                              dynamic
C:\Documents and Settings\gbrewster>
```

## Packets inside Frames

Terminology: IP packet is carried inside Ethernet frame. IP is encapsulated by Ethernet.



# It used to be worse: the OSI 7-layer model

- The original layered protocol model was the <u>7-</u>
   <u>layer Open Systems Interconnect model</u> (1977)
  - Theoretical model used to describe 7 separate layers of functionality required for end-to-end data communications
  - Useful to understand for historical context

## The 7 OSI Layers

#### with WWW examples


- Layer 7: Application Layer (ex: HTTP)
- Layer 6: Presentation Layer (ex: SSL encryption)
- Layer 5: Session Layer (ex: SSL authentication/login)
- Layer 4: Transport Layer (ex: TCP)
- Layer 3: Network Layer (ex: IP)
- Layer 2: Data Link Layer (ex: Ethernet Framing)
- Layer 1: Physical Layer (ex: Ethernet Hardware)

#### Figure 2.6 Summary of OSI Layers

Application To allow access to network resources Presentation To translate, encrypt, and compress data 6 To establish, manage, and terminate sessions 5 Session To provide reliable process-to-process Transport message delivery and error recovery To move packets from source to destination; Network to provide internetworking To organize bits into frames; to provide Data link hop-to-hop delivery To transmit bits over a medium; to provide Physical mechanical and electrical specifications

## Cisco Network Design Model

FIGURE 2.14 The Cisco hierarchical model



Used to categorize network device types and functions in a large enterprise network

# 3-Layer Network Design Model

#### Access Layer

- Contains hubs and switches that connect directly to user desktops and servers.
- Key features: switch port security, virtual LANs, multicast

#### Distribution Layer

- Contains layer 3 switches and/or routers that interconnect access layer switches and core backbone.
- Key features: redundancy, virtual LANs, access control lists, address translation (NAT), DHCP, multicast, RIP, EIGRP, OSPF.

#### Core Layer

- Contains high-end routers that form the backbone of the organizational network and connect to ISP or other AS.
- Key features: redundancy, highest reliability, highest data rates, minimize router features (for performance), EIGRP, OSPF, BGP.